



Fluke Calibration 2700G digital gauge

Setup for use with Fluke 700G/TRACK software


Note - The 2700G gauge must have firmware version 4.00 or higher to work with 700G/TRACK software. Version is shown on the gauge when powering it up. This gauge has version 4.01.




1. On your computer, open the Windows Device Manager window from the Start menu or from the Control Panel.
2. Expand the Ports (COM & LPT) line. The detected ports will be shown.
3. Right click the COM port of the 2700G or 700G digital gauge cable and select Properties to bring up the Properties window for that COM port.
4. On the General tab, the Manufacturer (of the driver and chipset) should show as FTDI and the Device Status should show "The device is working properly."
5. If not, follow the instructions in the Help menu of the 700G/TRACK software, specifically the "USB Cable Installation" section to install the driver for the USB cable.



6. Open the 700G/TRACK software
7. Choose the correct COM port as shown in Device Manager



8. Press the [Connect] button and wait for the gauge information to populate the fields



End of Setup Instructions.

See 700G/TRACK Help menu for software use instructions