Upgrade PostgreSQL Database for LogWare III Version 2.x

- 1) Download PostgreSQL 9.2 installer.
- 2) Stop the Fluke METBASE G2 Application Server service if it is running.



3) Uninstall PostgreSQL 8.1 if necessary.

🐞 Add or Ren	nove Programs			_ 🗆 ×
5	Currently installed programs:	Show updates	Sort by: Name	•
C <u>h</u> ange or Remove	🚟 AVG 2011		Size	128.00MB
Programs	🙀 Fluke METBASE G2 Application Server		Size	150.00MB
- E	🚟 LogWare III Client		Size 1	,007.00MB
Add New	🚟 LogWare III Server		Size	44.90MB
Programs	👸 Microsoft Visual C++ 2005 Redistributable		Size	5.25MB
1	🙀 Microsoft Visual C++ 2008 Redistributable - x86 9.0.3	0729.4148	Size	10.19MB
Add/Remove	🗬 PostgreSQL 8.1		Size	65.63MB
Components	Click here for support information.		Used	<u>rarely</u>
()	To change this program or remove it from your comput	ter, click Change or Remove.	Change	Remove
Set Program	VMware Tools		Size	34.15MB
Access and Defaults	🏉 Windows Internet Explorer 8		Size	4.22MB

4) Remove postgres user account.



5) Delete remaining PostgreSQL 8.1 files and folders.



6) Run PostgreSQL 9.2 installer.



7) Select the options on each dialog as shown below:

🕼 Setup			
Installation Directory			R
Please specify the directory where PostgreSQL will be insta	alled.		
Installation Directory C:\Program Files\PostgreSQL\9.2	6		
BitRock Installer	< Back	Next >	Cancel
		·	
13 Setup			- 0 ×
🕼 Setup			
😰 Setup Data Directory			
Setup Data Directory Please select a directory under which to store your data.			
Setup Data Directory Please select a directory under which to store your data. Data Directory [\Program Files\PostgreSQL\9.2\data]			_0×
Setup Data Directory Please select a directory under which to store your data. Data Directory [\Program Files\PostgreSQL\9.2\data]	ŝ		
Setup Data Directory Please select a directory under which to store your data. Data Directory \Program Files\PostgreSQL\9.2\data	ß		-DX
Setup Data Directory Please select a directory under which to store your data. Data Directory [Program Files]Postgre5QL19.2\data]	Ê		
Setup Data Directory Please select a directory under which to store your data. Data Directory [\Program Files\PostgreSQL\9.2\data]	ő		
Setup Data Directory Please select a directory under which to store your data. Data Directory \Program Files\PostgreSQL\9.2\data	ß		
Setup Data Directory Please select a directory under which to store your data. Data Directory [Program Files]PostgreSQL19.2\data]	<u>6</u>		
Setup Data Directory Please select a directory under which to store your data. Data Directory [\Program Files\PostgreSQL\9.2\data]			
Setup Data Directory Please select a directory under which to store your data. Data Directory [\Program Files\PostgreSQL\9.2\data]	ß		

Must use **FlukeMetBase1!** As the password!! Note this is case-sensitive!



🕼 Setup		×
Port		ļ
Please select the port number the server should listen o Port 5432	n.	
BitRock Installer	<pre> < Back Next > Cancel</pre>	

🤣 Setup	
Advanced Options	P
Select the locale to be used by the new database cluster Locale [Default locale]	
BitRock Installer	< Back Next > Carrel

🥼 Setup		<u>_ ×</u>
	Completing the PostgreSQL Setup Wizard	
h h dl	Setup has finished installing PostgreSQL on your computer.	
	Launch Stack Builder at exit?	
	Stack Builder may be used to download and install additional tools, drivers and applications to complement your PostgreSQL installation.	
PostgreSQL		
Packaged by:		
Enterprise DB®		
	< Back Finish	Cancel

- 8) Reboot the computer.
- 9) After computer has been logged in to Windows for about 2 minutes, run LogWare application.

10) Apply license.

11) Login using user LogWare password LogWare